PREMIER®

MANUAL DE INSTRUCCIONES

MINI-PARLANTE C/BLUETOOTH

MS-5196SDBT

ESTIMADO CLIENTE

Con el fin de que obtenga el mayor desempeño de su producto, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo, y guárdelo para su futura referencia.
Si necesita soporte adicional, no dude en escribir a: ***info@premiermundo.com***

ÍNDICE

CONTENIDO 2
DESCRIPCIÓN 2
FUNCIONES DEL PARLANTE 2
BATERÍA 3
BLUETOOTH 3
MODO DE **TARJETA** 4
FUNCIÓN DE MEMORIA 4
CONEXIÓN 4
TRANSMISIÓN DE DATOS 5
INSTRUCCIONES DE SEGURIDAD 5
ESPECIFICACIONES 5


PRECAUCIÓN
RIESGO DE CHOQUE ELÉCTRICO , NO ABRA
Precaución: Para reducir el riesgo de choque eléctrico, no retire la cubierta, no hay partes manipulables por el usuario al interior de la unidad. Refiera todo mantenimiento o intervención técnica a personal técnico calificado.
Este símbolo indica la existencia de voltaje peligroso al interior de esta unidad, que constituye un riesgo de choque eléctrico.
Este símbolo indica que hay importantes instrucciones de operación y mantenimiento en la literatura que acompaña a esta unidad.

LÍNEAS DE SERVICIO AL CLIENTE PREMIER

Venezuela:	0800 – ELECTRIC (353-2874)
Panamá:	300-5185
Sitio Web:	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTA
Nos reservamos el derecho de modificar las especificaciones, características y/u operación de este producto sin previo aviso, con el fin de continuar las mejoras y desarrollo del mismo.

CONTENIDO

- 1 parlante Bluetooth
- 1 cable de datos USB
- 1 cable de audio de 3.5mm
- 1 cuerda de algodón
- 1 adaptador AC
- 1 manual del usuario

DESCRIPCIÓN



1. Siguiente/Volumen +
2. Play/Pausa/Contestar
3. Anterior/Volumen-
4. Modo
5. Encender/Apagar

FUNCIONES DEL PARLANTE

- Conexión Bluetooth 2.0 para todos los dispositivos con esta función.
- Micrófono incorporado para que utilice el dispositivo como manos libres.
- Reproducción de micro tarjeta SD.
- Batería recargable de larga duración. Hasta 4 horas de operación.
- Cable USB con doble funcionalidad: para cargar el parlante y para transmitir datos.
- Conector de audio 3.5mm.



BATERÍA

Usted puede disfrutar de hasta 4 horas con la batería recargable incorporada.
Antes de usar la batería por vez primera cárguela por 10 horas para obtener el mejor desempeño. Luego sólo será necesario cargarla por 2 horas. Si no la va a utilizar por un período prolongado se recomienda cargarla al menos una vez al mes.

AHORRO AUTOMÁTICO DE ENERGÍA

Si la operación se pone en modo de pausa por más de 2 minutos, el parlante se apagará automáticamente.

BLUETOOTH

Verifique que el dispositivo que quiere conectar cuente con la función Bluetooth.
Encienda el parlante manteniendo presionado el botón de encendido hasta que escuche un sonido “ding dong”. El parlante comenzará en la primera función por defecto que es Bluetooth y la luz indicadora se encenderá de color azul y parpadeará rápidamente para buscar su dispositivo.

Ingrese la contraseña

Cuando el parlante y el otro dispositivo Bluetooth se enlacen, el dispositivo Bluetooth recibirá una señal mostrando el modelo del parlante MS-5196SDBT. Introduzca la contraseña por defecto 0000 para completar el enlace.

CONTESTAR UNA LLAMADA ENTRANTE

Si está reproduciendo música en el parlante y se recibe una llamada telefónica, la música se pausará automáticamente y entrará al modo de llamada. Presione el botón de Teléfono en el parlante para contestar. Con el micrófono incorporado en el parlante usted será escuchado perfectamente.

Contestar



Teléfono

MODO DE TARJETA

Inserte una tarjeta SD en la ranura y seleccione el modo de tarjeta SD del parlante.
Utilice los botones normalmente para reproducir la información de la tarjeta.



FUNCIÓN DE MEMORIA

Al estar reproduciendo una pista, si de repente se va la energía, una vez se reanude la unidad recordará el punto donde se detuvo y continuará a partir de ahí. Lo mismo sucede con el ajuste de volumen, el cual se mantendrá igual cuando se reanude la operación.

CONEXIÓN

Utilice los conectores de 3.5 para conectar una unidad exterior como fuente de sonido, y para conectar sus audífonos.



Usted puede utilizar la entrada de audio con cualquier dispositivo que tenga esta salida de sonido, como por ejemplo, computadores, teléfonos celulares, reproductores de CD, etc.



TRANSMISIÓN DE DATOS

Al conectar el parlante al computador por medio del cable USB usted puede transmitir información del computador al parlante. Utilice el parlante como una memoria USB tradicional en la cual puede añadir o eliminar datos.

Recuerde no desconectar el cable USB cuando se está haciendo una transferencia de datos.

⚠ *INSTRUCCIONES DE SEGURIDAD*

- Mantenga la unidad fuera del alcance de los niños.
- Evite que la unidad se caiga y se golpee.
- Mantenga la unidad lejos del agua y no la coloque en lugares con temperaturas muy altas son muy bajas.
- No intente reparar la unidad usted mismo. Remita toda revisión, mantenimiento y reparación a personal de servicio técnico calificado.

ESPECIFICACIONES

Categoría	Elemento	Especificación
Bluetooth	Versión	Bluetooth 2.0
	Frecuencia	2.4 – 2.48GHz
	Rango de operación	10 metros
	Protocolo de comunicación	HS/HF, A2DP, AVRCP
Audio	Unidad de controlador	50.8mm
	RMS	3 watts
	Frecuencia	100Hz – 18KHz
	Relación señal a ruido	≥57dB
	Impedancia	4 ohm
	Distorsión	≤11%
Soporte de archivos	Formatos de música	MP3
Tarjeta de memoria	Soporte	Micro Tarjeta SD
	Lectura de tarjeta	Función activa
Energía	Batería	Li-on recargable
	Voltaje	DC 3.7V
Puertos	Puerto de carga y de datos	Puerto Micro-USB

- Las personas y/o Marcas registradas en este manual de instrucciones no están afiliadas a Premier Electric Japan Corp. y aparecen en este Manual con propósitos ilustrativos únicamente.

PREMIER®

INSTRUCTION MANUAL
BLUETOOTH SPEAKER
MS-5196SDBT

DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.
If you need extra support, please write to ***info@premiermundo.com***


CAUTION
RISK OF ELECTRIC SHOCK, DO NOT OPEN
Caution: To reduce the risk of electric shock do not open this device, there are not serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.
This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.
This sign means that there are important instructions of operation and handling in the manual that comes with this device.

PREMIER CUSTOMER SERVICE

Venezuela:	0800 – ELECTRIC (353-2874)
Panama:	300-5185
Website	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTE
This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

Chapter 1:Simple Instructions

1.1 Accessories
-Bluetooth speaker×1
-USB Power/data cable×1
-3.5mm Audio cable×1
-Cotton Rope×1
-User guide×1
-AC Adapter×1

1.2 Outer Constructions



□NEXT/VOL+
□Play/Pause/Answer
□PREV/Vol-
□Switch mode
□Power ON/OFF

1.3 Speaker Functions

Bluetooth 2.0 for all of your devices with built-in Bluetooth function.
Built-in Microphone gives you a hands-free call,press the phone button answer the phone under Bluetooth mode.
Support TF Card and TF card is universal plug and play.
Play format:MP3
Rechargeable LI-ON Battery with a long working time up to 4 hours
Three-in-one data line
USB data cable,you can use it achieve rechargeable lithium battery,USB sound card connection and data transfer three functions.
3.5mm AUX IN
Universal 3.5mm Line-in for all of your devices with audio output.
Speaker USB sound card,use USB data cable connect the speaker and computer play music,you can directly control your computer's music player turn

next song.
Card reader function



Chape 2:Li-on battery Notice
You will enjoy music up to 4 hours,as there is 1 built-in high capacity rechargeable li-on battery.



2.1 Precautious
To activate it best performance of the battery,please charge the speaker up to 10 hours before you fist using.
Every month you need to recharge it one time at least if you don't use it for a long time.
As this is a charger capacity battery, you must use a standard 5V-1A charger.Use of less than 5V-1A charger cause charge to fail.
2.2 State of charging
Charging red light flash quickly,full charged,the red light flash slow.
2.3 Automatic power saving mode
In TF card,LINE-IN and Bluetooth mode pause playback,audio will shut down automatically without any operation after five minutes,work indicator light go out.
Chapter 3 Bluetooth wireless connection
3.2 Turn on your speaker by press/hold the power on/off button until you hear a sound of "dingdong".Then it will go into the 1st default mode"bluetooth" and the blue indicator light will flash quickly to search your bluetooth device.
3.3 When your speaker and other bluetooth device find them each other,your bluetooth device will receive a signal saying"MS-5196SDBT". Please enter the default password"0000" and then they will be paired

successfully.If you are fail to pair them,pls try it again as per these steps.



3.4Answer Incoming Phone

When play music with Bluetooth connective, if there have phone call in, the music will automatically pause and turn incoming calls state. It would autoreply the current operating mode after the call finish.

Press the botton to answer the call, the built-in MIC will bring you a clear call experience.



Chapter 4 Play Music

4.1 TF Card music player operations

Default boot into reader mode (TF card), then you can insert the TF card play songs, now it only support MP3 audio file.

When reader mode, the system light flashes slowly, the light turn into red after pull TF out.

- PREV./Vol-

+ NEXT/VOL+

Short press: in the TF card mode and Bluetooth mode to paly next songs, it’s invalid in the audio input mode.

Long press: to increase the volume



Chapter 5 Memory Function

5.1 The way of memory function

1. Track List Memory: Speaker playing a song, if a sudden power failure or shutdown, the speaker will record the moment of play state, it will directly play from the record moment next time.

2 .Volume Memory: In any mode, adjust the volume, the volume memory will not change whether it is switched off, poweroff or shutdown ,when it power off when the volume is less than half, it will automatically jump back to the default value of 10.

Chapter 6 Audio Input/Output

6.1 Audio input basic operation

Use the 3.5mm audio cable to connect with computer/mobiles/MP3 players, then it can play music, the system light will turn into red

6.2 Audio output basic operation

When your earphone/headset inserted , it will transmit audio into your device, and the speaker will be quiet.

3.5mm audio input interface



3.5mm audio output interface

6.3 Devices witch can use audio input

All devices with 3.5mm audio interface mobile phones, computers, CD and MP3, Ipad,tablets.



Chapter 7: Data Transmission
7.1 Basic operation of setup mode
When boot state, connect to the computer can enter the USB card reader mode, also supports USB audio mode at the same time.
It can operate the file directly in the computer.
7.2 FAQs
--data transmission function can only use when the speaker already started up.
--if can not found storage device when connect with the computer.
First check weather the speaker is turned on, then check the USB cable, if possible, try each USB port of your computer.
--if all USB port does not respond, you will need to reinstall the drives---USB Composite Devece & USB Mass Storage Device. First uninstall those drives then use USB digital cable to connect with your computer, it will automatically
reinstall these two drivers.

chapter8:Specifications

Category	Item	Specifications
Bluetooth	Version	Bluetooth 2.0
	Frequency	2.4~2.48GHZ
	Working Distance	10m
	communication protocol	HS/HF,A2DP,AVRCP
Auduio	Driver unit	50.8MM
	RMS	3W
	Frequency	100HZ~18KHZ
	SNR	S/N≥57DB
	Impedence	4.0Ω
	Distortion	THD≤11%
Supported files	Music format	Mp3
Memory Card	Support	TF Card
	Card Reader	Card Reader function
Power	Battery	Built-in rechargeable Li-on battery
	Volt	DC 3.7V
Ports	Charge/Data port	Micro USB Port

Warnings:
1.Not toys for Children
2.To avoid/minimize artificial damage,Please do not beat it crazily or drop itOnto the solid floor.
3.Free your speaker from water,high Temperature,and too cold conditions.
4.For any function problems,please send them back to the service center,Pls do not open it privately,if you are not an electronic engineer.
5.After a long time using,maybe there will be some natural oxidized issues(likerusts, painting-droop off).Such issues are not in our guarantee service.